


HTS - SERIES

BUL86261

REV. A

ASSEMBLY INSTRUCTIONS FOR HTS - HME TOP PANEL



Removal Instructions:

A) Loosen eye bolts (May require the use of a screwdriver or a bar to get it started). Larger top panels have a thread rolling screw in the center that needs to be removed as well.


B) Loosen and remove self-tapping screws and O-rings.

C) Lift top panel off.

Installation Instructions:

A) Line holes on top panel up with holes on top of the frame.

B) Install eye bolts with washers and tighten down so compression stop touches top frame. Also install center thread rolling screw if needed.



**HAMMOND
MANUFACTURING™**
www.hammondmfg.com