

Alpha Wire Part Number Ordering Guide (FIT® Products)

Step 1:

Which Alpha Wire FIT® Series ?	
AW Series	Web/Cat Cross Reference
F221	FIT221 & FIT-221
G130	GRP130 & GRP-130
PF200	PIF200 & PIF-200
P1051	PVC105 & PVC-105-1

Step 2:

Use your Alpha Wire Item Number
F2213/16
F6001IN
FNT3/8
G110NF34

Step 3:

Then choose color, use 2 character abbreviation to add to the Alpha Wire item number

Color	Color Desc.
BK	Black
BL	Blue
BR	Brown
CL	Clear
GR	Green
GY	Green/Yellow
MC	MultiColor
NA	Natural
NC	No Color
OR	Orange
RD	Red
SL	Slate
SV	Silver
WH	White
YL	Yellow

Step 4:

Then choose Put-up Code for product, use the 3 digit abbreviation to add to the Alpha Wire order number

Put-up Code	Putup Desc.	Put-up Code	Putup Desc.
001	1000 FT	074	1X6 IN
002	500 FT	076	1C PC/PKG
003	250 FT	078	25 PC/PKG
004	200 FT	080	10 PC/PKG
005	100 FT	082	250 PC/PKG
007	50 FT	083	500 PC/PKG
008	25 FT	088	500 YDS
009	10 FT	089	250 YDS
015	125 FT	100	250X4 FT
016	150 FT	103	25X4 FT
017	70 FT	105	5X4 FT
018	65 FT	107	2X4 FT
019	60 FT	112	50X2 FT
020	40 FT	113	25X2 FT
024	35 FT	114	10X2 FT
025	32 FT	132	6X12 IN
026	24 FT	147	1000X1 IN
028	16 FT	161	1000X1/2IN
031	75 FT	171	2000X4 FT
032	EACH	180	48 IN BULK
056	6X6 IN	194	6 IN BULK
059	40X6 IN	196	12 IN BULK
060	36X6 IN	199	BULK FT
061	32X6 IN	201	2X150 FT
062	28X6 IN	202	2X200 FT
063	24X6 IN	203	2X250 FT
064	20X6 IN	204	2X500 FT
065	16X6 IN	205	3X1000 FT
066	14X6 IN	206	3X500 FT
067	12X6 IN	207	125X4 FT
068	10X6 IN	209	75X4 FT
069	8X6 IN	210	200X4 FT
070	5X6 IN	213	60X6 IN
071	4X6 IN	257	36 FT
072	3X6 IN	269	15 FT
073	2X6 IN	270	14 FT

Step 5:

Item Number: F2213/16

Item Color: Black

Item Put Up: 100 Ft

Part Number System: F2213/16 BK005

Item Number: G1303/4

Item Color: Orange

Item Put Up: 2x150 ft (300ft)

Part Number System: G1303/4 OR201

Final Step Order Your Alpha Wire!



FIT Heat-Shrink Tubing



FIT Sleeving



FIT Tubing



FIT Braid



FIT Lacing Tape



FIT EMI Tape



FIT Accessories