# Mini-Com TX5e and TX6 PLUS UTP Jack Modules


Part Numbers: CJ5E88T**, CJD5E88T**, CJ688TP**, CJD688TP**, KJ688TP**

© Panduit Corp. 2015


**INSTALLATION INSTRUCTIONS**

**PN307K**


## 1





## 2





## 3




## 4





## 5





## 6




## 7





## 8




***For Technical Support: www.panduit.com/resources/install_maintain.asp***

** Denotes color.


## TERMINATION CAP REMOVAL





## JACK MODULE INSTALLATION / REMOVAL

### Mini-Com style jack modules

**INSTALL**





**REMOVE**





### Keystone style jack modules

**INSTALL**




**REMOVE**





**Notes:**

1. For specified performance, follow ANSI/NECA/BICSI-568-2006 installation guidelines.
2. Jack modules can terminate PVC or Plenum rated 22-24 AWG solid or stranded IWC cable with insulated conductor outside diameter ranging between 0.035 inch (0.88mm) and 0.048 inch (1.2mm).
3. Jack modules may be re-terminated a minimum of 10 times.
4. For technical and performance information, consult Panduit Technical Support.

**As with all Wiring Accessories, the following statements apply:**

1. Never install communications wiring during a lightning storm.
2. Never install communications wiring in wet locations unless the jack is specifically designed for use in wet locations.
3. Never touch uninsulated communications wiring or terminals unless the communication line has been disconnected at the network interface.
4. Use caution when installing or modifying communication wiring.

### Wiring Sequences




**For Instructions in Local Languages and Technical Support:**
www.panduit.com/resources/install_maintain.asp

PANDUIT
www.panduit.com

**E-mail:**
techsupport@panduit.com

**Phone:**
866-405-6654


# Termination for Right Hand Lay Cable

© Panduit Corp. 2015


**INSTALLATION INSTRUCTIONS**

**PN580A**


**1**





**2**





**3**




**4**





**5**





**6**




**7**




**8**




***For Technical Support: www.panduit.com/resources/install_maintain.asp***